


## AV WALL PANEL




Note: If you are switching between the VGA input and the HDMI input there will be a 10 second delay before your image appears.

You can only have either a VGA or HDMI cord connected. If both cords are plugged in at the same time then the system gets confused and will not work.

A VGA cable is provided. Bring your own computer adaptor.

## AV RACK



### AUDIO SOURCES

- AUX 1 = VHS
- AUX 2 = VCR/DVD
- AUX 3 = BLURAY
- AUX 4 = HDMI
- AUX 5 = CD PLAYER

You must have a key to access the AV rack. Contact key issues for a permanent key or Media Loan for a temporary check out.