



326 SCREENING ROOM



AV CONTROLLER




Media Rack located on the Media Desk



Black external AV rack



326 A CONTROL ROOM



Bluray1 - selects audio input for control room deck

Bluray2 - selects audio input for front room deck

326A - selects audio input for any source plugged into the back control room.

326 - selects audio input for any source coming from the RANE Audio Mixer on the front desk.

All these main power switches must be ON in order for the system to work