

LONGHOUSE A/V

COMPUTER HAS NO AUDIO/PICTURE

Have you configured your mirroring settings?

MAC*:

Go to:

- 1.) 'System Preferences'
- 2.) Click 'Displays'
- 3.) Check the box 'Show mirroring options in the menu bar when available'

* *You may need an adaptor, contact Media Loan x6253*

PC:

Go to:

- 1.) 'Start'
- 2.) 'Control Panel'
- 3.) 'Display'
- 4.) Project to a Second Screen
- 5.) Select -

> 'Duplicate' for the same image projected
> 'Extend' for two different images (good for powerpoint)

Is your computer correctly connected?

Have you checked your cable connection?

Are you using an adaptor?
Is the adaptor not hanging off a ledge or desk?

Is that cable correctly selected as the input source?


Not sure?

Check the source selection on the switcher and double check that you have the same cable and source selected.


The VGA cable looks like this:



The HDMI cable looks like this:





1007B



COMBINING PROJECTOR IMAGES

- 1.) Connect your laptop or external device (VCR or DVD Player) to the wall panel in 1007B.
- 2.) Adjust the switch on the 1007B panel from 'separate' to 'combine'
- 3.) Turn on both projectors and lower screens
- 4.) Return the switch to 'separate' once finished using the combine function

1007A



STILL NEED HELP?

CALL x6270

FOR CLASSROOM SUPPORT