


COM 308

AV WALL PANEL




Note: If you are switching between the VGA input and the HDMI input there will be a 10 second delay before your image appears.

You can only have either a VGA or HDMI cord connected. If both cords are plugged in at the same time then the system gets confused and will not work.

A VGA cable is provided. Bring your own computer adaptor.

AV RACK



You must have a key to access the AV rack. Contact key issues for a permanent key or Media Loan for a temporary check out.