

SEMINAR II A/V CABINET

2nd and 3rd Floors Only

TROUBLESHOOTING

COMPUTER HAS NO AUDIO/PICTURE

Have you configured your mirroring settings?

Mac*:

Go to:

- 1.) 'System Preferences'
- 2.) Click 'Displays'
- 3.) Check the box 'Show mirroring options in the menu bar when available'

PC:

Go to:

- 1.) 'Start'
- 2.) 'Control Panel'
- 3.) 'Displays'
- 4.) Project to a Second Screen
- 5.) Select -

> 'Duplicate' for the same image projected
> 'Extend' for two different images (good for powerpoint)

Is your computer correctly connected?

- 1.) Have you checked your cable connection?
- 2.) Are you using an adaptor? Is the adaptor not hanging off a ledge or desk?
- 3.) Is that cable correctly selected as the input source?

Not sure?

Check the source selection on the switcher and double check that you have the same cable and source selected.

The VGA cable looks like this:



The HDMI cable looks like this:



AC POWER

Use for powering things such as laptops.

MAIN POWER

Must be on to use the A/V rack functions.

MAIN VOLUME

Adjust volume for any input selected in the A/V rack.

INPUT 7

Connect your device, must be selected as the projector input.

CD/DVD

Must be turned on and selected as the projector input.

VCR

Must be turned on and selected as the projector input.

NO AUDIO/PICTURE

- 1.) Check that the 'Main Power' is on.
- 2.) Check that the input source matches the device your using.
- 3.) Check that the 'Main Volume' is turned up.
- 4.) Press 'Play' if applicable.



Still Need Help?
Call x6270
For Classroom Support

* Some Mac laptops require adaptors - Contact Media Loan for more information.